

UTEGRUND 2 in 1

Product description:

Utegrund 2 in 1 is a new type of primer that replaces the previously traditional system with base oil and outdoor primer.

The product binds loose wood fibers and ensures good adhesion prior to the final coating. The special pigmentation protects the wood from harmful UV light and has a color similar to new unexposed wood. Utegrund V 2 in 1 makes the surface water-repellent and reinforces and protects against natural aging, the entire color system achieves increased durability. The product contains film-preserving substances against algae and mold.

Used before applying Colorex Titan or Storm on all new and weather-resistant wood. Stir well before use. Substrates treated with linseed oil or linseed with linseed oil should be cleaned down to untreated wood, as old linseed oil may cause blistering at later treatment with topcoat.

TECHNICAL DATA:

Area of application	Outdoor
Binder	Alkyds
Volume Solids	25%
Density	1,02
Gloss	Semigloss
Washability	Class 1 (EN 13300)
Thinner/Cleaning	Water
Material consumption	6-10 m ² /L
Temperature at painting	Minimum +5°C
Tools for painting	Brush, roller and spray
Dust dry	1 h
Re-paintable	2-4 h
Completely dry	24-48 h
Shelf life	2 years in unopened tin, frostless storage
Colour	Transparent
Flammability	Not flammable
VOC category	(Cat. A/d): 130 g/l (2010)

UTEGRUND 2 in 1

How to use

Pre-painting

The surface must be clean, firm and dry: Grind sharp edges. Panel that has been left untreated should be cleaned and loose wood fibers removed.

Previously painted surfaces are washed with products intended for washing before painting and then allowed to dry well. In fungal and algae arrest, the surface should be treated with suitable disinfectant. Loose paint and loose wood fibers should be scraped / brushed off.

Prime clean wood surfaces.

Painting

Utegrund 2 in 1 should be brushed on and worked well into the wood, avoiding drying the product. Do not terminate in the middle of the panel, but apply the product in the entire length of the panel boards. The foundation must be removed carefully.

New wood is treated before or immediately after fitting with an iron Utegrund 2 in 1.

Carefully brush out the primer. Bare wood is applied 3-4 strokes wet-on-wet. The panel should be finished with the desired product within 1 month. Paint at least two layers with the end product.